

## Packing List



**Sealing Plug  
for B-NANO Handle** ..... 10 units



**Manual** ..... 1 unit  
Ref. 0032718

0032718-290724

OB5000 sealing plugs work exclusively with B-NANO handles.

**Note:** Check the condition of the plug periodically and replace it as soon as wear or cracking is detected.

# JBC


www.jbctools.com

## INSTRUCTION MANUAL



### OB5000


**Sealing Plug  
for B-NANO Handle**




www.jbctools.com




## Replacing the Sealing Plug


 For B·NANO handles, the use of the sealing plug is mandatory. Without the use of the sealing plug, the cartridges cannot be properly inserted.



Remove the worn sealing plug by unscrewing it by hand.



Position the chamfered side upwards and screw the new sealing plug into the handle bushing until it stops.



Make sure the sealing plug is placed correctly. The shoulder of the plug must be in touch with the bushing.